


SATATYA Ruggedized IP-Camera

The Persistent Vision



Safety Instructions

These instructions are intended to ensure that the user can use the product correctly to avoid danger or property loss.

Cautions

- Ensure that the power supply voltage is correct before using the camera.
- Avoid placing cables too close to magnetic or high voltage devices, to reduce undesirable image noise.
- Do not touch sensor modules with fingers. For cleaning use 'clean cloth' and wipe it gently.
- Do not mount the camera with the lens facing the sun or bright light to prevent damage to the sensor.
- Do not expose the camera to temperatures below or beyond its operating temperature.
- Do not mount the camera near a radiator or a heater.

Warning

- In the use of the product, you must be in strict compliance with the electrical safety regulations of the region and nation.
- Do not connect several devices to one power adapter as it may cause over-heating or fire hazard.
- If smoke, odour or noise rise from the device, turn off the power at once and unplug the power cable, and contact the nearest service center.
- To prevent electrical shock, turn off power supply before making electrical connections.

Consignes de sécurité

Ces instructions ont pour but de garantir que l'utilisateur peut Utilisez le produit correctement pour éviter tout danger ou perte de propriété.

Précautions

- Vérifiez que la tension d'alimentation est correcte avant d'utiliser l'appareil photo.
- Évitez de placer des câbles trop près d'une tension magnétique ou élevée périphériques, pour réduire le bruit d'image indésirable.
- Ne touchez pas les modules de capteur avec les doigts. Pour le nettoyage, utilisez nettoyer chiffon et essuyez-le doucement.
- Ne montez pas l'appareil photo avec l'objectif dirigé vers le soleil ou vers lumière pour éviter d'endommager le capteur.
- N'exposez pas l'appareil photo à des températures inférieures ou supérieures à ses température de fonctionnement.
- Ne montez pas la caméra à proximité d'un radiateur ou d'un appareil de chauffage.

Attention

- Dans l'utilisation du produit, vous devez être en stricte conformité avec les réglementations de sécurité électrique de la région et de la nation.
- Ne connectez pas plusieurs périphériques à un seul adaptateur secteur, provoquer une surchauffe ou un risque d'incendie.
- Si de la fumée, des odeurs ou du bruit émanent de l'appareil, éteignez-le une fois, débranchez le câble d'alimentation et contactez le service d'assistance le plus proche centre.
- Pour éviter un choc électrique, éteignez l'alimentation avant de connections électriques.

Contents

Know your Camera	6
What your Package Contains	7
Things you will Need	7
Camera Variants	7
Installation Instructions	9
Installing Mounting Template	10
Mounting the Bottom Enclosure	12
Adjusting Camera Angle	14
Accessing the Reset Switch and SD Card	17
Mounting the Camera	18
Connecting the Camera	20
Powering the Camera	22
Network Configuration	24
Accessing via Web Browser	25
Technical Specification	29

Please read this guide first for correct installation and retain it for future reference. The information in this guide is prevailing at the time of publication. However, Matrix Comsec reserves the right to make changes in product design and specifications without prior notice.

Copyright

All rights reserved. No part of this document may be copied or reproduced in any form or by any means without the prior written consent of Matrix Comsec.

Warranty


Limited Warranty. Valid only if primary protection is provided, mains supply is within limit and protected, and environment conditions maintained within product specifications.

Complete warranty statement is available on our website:

www.matrixvideosurveillance.com

Know your Camera

Figure 1



- 1. Cable Guide
- 2. Cable Assembly
- 3. Damping Rubber
- 4. Bottom Enclosure

- 5. Top Enclosure
- 6. Dome Glass Cover
- 7. Hole for Mounting

What your Package Contains

- SATATYA Ruggedized IP Camera Unit
- Wall Mounting Template
- Wall Mounting Screws with Screw Grip (3 nos.)
- Cable Accessories
- Allen Key


Things you will Need

- A Power Drill, Screwdriver Set, Pliers, Wire-cutter, Ladder.
- Necessary Cabling.

Camera Variants

The SATATYA Ruggedized Camera's **Premium** variants are:

- 2MP variants with 2.8mm, 3.6mm and 6.0mm fixed focal length.
- 5MP variants with 2.8mm, 4.0mm and 6.0mm fixed focal length.

 You can capture near and broader view with lens of 2.8mm and 3.6/4 mm focal length. For example it can be used in ATM and Elevators.

With lens of 6 mm focal length, far and narrow view can be captured. For example it can be used in corridors or long passage to capture long view.

The available camera variants are listed in the table below:

2MP Camera Variants

Type of Lens	Focal Length	Variants
Fixed	2.8mm	RIDR20FL28CWP
Fixed	3.6mm	RIDR20FL36CWP
Fixed	6.0mm	RIDR20FL60CWP

5MP Camera Variants

Type of Lens	Focal Length	Variants
Fixed	2.8mm	RIDR50FL28CWP
Fixed	4.0mm	RIDR50FL40CWP
Fixed	6.0mm	RIDR50FL60CWP

Installation Instructions

Before you start

Please make sure,

- The device in the package is in good condition and all the assembly parts are included.
- All the related equipments are powered-off before installation.
- The wall or ceiling is strong enough to support the weight of camera.

Step 1: Select a Location

- Select a suitable location for your camera to enable coverage of the intended surveillance area. The location should preferably be a flat surface, such as a Wall or a Ceiling.


Step 2: Prepare for Installation

- Make sure you arrange a cable suitable for both power and data transmission. This cable should have a M12 4-PIN Male connector on one end for the camera and an appropriate connector on the other end for the Mobile NVR device or client. Additionally, confirm that the cable is rated for power requirements of the camera.
- Provide proper connectivity between camera and recording location through LAN cable.
- It is advisable to make concealed wiring. However, wiring can also be done externally.

Step 3: Installing Mounting Template

- Stick the Mounting Template at the exact location of camera installation. The location can be a Ceiling or a Wall.
- Drill three holes through the markings provided on the Mounting Template on Wall or Ceiling.
- Insert the screw grips in the holes you drilled, see **Figure 2**.
- In case of concealed wiring, a separate hole has to be drilled in the center for cable outlet.

Figure 2



Step 4: Arranging the cables

For External Cabling:

- Pull the cable out through the cable guide, sideways to the camera, see **Figure 3a**.

For Concealed Cabling:

- Insert the main-cabling through the center hole and make proper connection with LAN Cable, see **Figure 3b**.

Figure 3a






Figure 3b



Step 5: Mounting the Bottom Enclosure

- To mount the camera, you need to detach the Top Enclosure.
- Use the Allen Key to loosen the Retainer screws on three sides of the camera body, as shown in **Figure 4a**.
- The Retainer screws will still remain loosely connected.
- Now, pull the Top Enclosure downwards. The Top and Bottom Enclosures are detached.

Figure 4a



- Align the Bottom Enclosure with the mounting screw holes drilled earlier.
- Now, affix the Bottom Enclosure with the three screws provided along with the camera, see **Figure 4b** and **Figure 5**.

Figure 4b





Figure 5




Step 6: Adjusting Camera Angle

Before you affix the camera Top Enclosure, you need to set the desired angle and position of the camera.

Loosen the camera screw with the help of a screwdriver, see **Figure 6**. Make sure you do not turn the screw more than 3 to 4 turns, else it may result in free fall.


Figure 6



PAN / Tilt / Rotation


For **PAN Movement** you can move the camera angle from -30° to $+30^{\circ}$.

Figure 7




For **Tilt Movement**, you can move the camera angle from minimum -10° to maximum $+90^{\circ}$.

Figure 8




For **Rotation**, you can move the camera angle from -175° to $+175^{\circ}$.

Figure 9



After you set the PAN, Tilt and Rotation angles, tighten the camera screw.

Figure 10




Step 7: Accessing the Reset Switch and SD Card Slot

If you forget the IP address or login credentials of camera then the camera can be reset to factory default settings using the reset switch.


- The Reset switch is located as shown in **Figure 11a**. Press the Reset switch for minimum 5 sec and release the switch to reset the camera to default settings.

Figure 11a



- You can insert the SD card in the slot to store your camera recordings, see **Figure 11b**.

Figure 11b



Step 8: Mount the Camera

- Align the Top Enclosure with Bottom Enclosure.
- Affix Top Enclosure with the Bottom Enclosure and tighten the Retainer screws using the Allen Key, see **Figure 12**.
- The Top and Bottom Enclosures are affixed together, see **Figure 13**.

Figure 12





Figure 13



Connecting the Camera

1. Power: Connect the M12 4-Pin Male connector of the cable to the M12 4-Pin Female connector of the camera cable. Make sure the pins are aligned, and if there is a threaded connection, make sure you secure it properly as M12 connectors often have threaded design for secure connection.

Connect the other end of the M12 4-Pin Male connector cable to the Mobile NVR device or client. Make sure the pins are aligned and secure the connection.

OR


You can also connect a 12V DC Adapter (not provided by Matrix) to power the camera. Make sure you use a BIS, CE, ROHS and FCC approved Adapter.

2. Audio Input: You can connect the **Audio Input** device such as Mike to the Audio input cable of the camera. The audio when enabled will be recorded with the video and will be available at the monitoring location.

3. Audio Output: You can connect the **Audio Output** device such as Earphone or Speaker to the Audio Output cable of the camera. This will generate audio received from the network.

4. Alarm IN: To detect alarm events you can connect a Sensor Device to the **Alarm IN** cable of the camera.

5. Alarm OUT: To get alerts on alarm you can connect the alarm sounding device such as hooter or siren to the **Alarm OUT** cable of the camera.



💡 If you are connecting devices such as Mic and Speaker to the Audio IN and Audio OUT, you may need to connect an external power source if their power requirements are not fulfilled with the camera adapter.

💡 If you are connecting devices such as Sensor and small Buzzers to the Alarm IN and Alarm OUT, you may need to connect an external power source if their power requirements are not fulfilled with the camera adapter.

Powering the Camera

Connect the M12 4-Pin Male connector of the cable to the M12 4-Pin Female connector of the camera cable.

Make sure the pins are aligned, and if there is a threaded connection, make sure you secure it properly as M12 connectors often have threaded design for secure connection.


Connect the other end of the M12 4-Pin Male connector cable to the Mobile NVR device or client. Make sure the pins are aligned and secure the connection.

OR

You can also connect a 12V DC Adapter (not provided by Matrix) to power the camera. Make sure you use a BIS, CE, ROHS and FCC approved Adapter.

M12 4-PIN
Female
Connector

DC
Connector



LED: CLASS1 (Category RS1)



Never look at the transmit laser while the power is on. Never look directly at the fiber ports and the fiber cable ends when they are powered on.

Use of controls or adjustment to the performance or procedure other than those specified herein may result in hazardous laser emission.

Network Configuration

To view and configure the camera via LAN (Local Area Network), you need to connect the network camera in the same subnet with your PC. Then install the software to configure the IP address.

Steps to get the IP Address

- Once the camera is connected to the network, it will automatically be assigned a dynamic IP address by the DHCP server. You can view the assigned IP address through any IP scanner utility.
- If DHCP server is unavailable or is not able to provide an IP address then **192.168.1.126** will be set as default IP address.
- You can change the IP address and subnet mask of Camera from the Basic Settings page of camera.

A screenshot of the 'IP Address Settings' web interface. The interface is divided into two main sections: 'IP Address Configuration' and 'DNS Configuration'.
IP Address Configuration:

- Host Name: matrix-cam12
- IP Configuration: Static
- IP Address: 192.168.104.38
- Subnet Mask: 255.255.255.0
- Default Gateway: 192.168.104.1

DNS Configuration:

- DNS: Specified Auto
- Preferred: 192.168.100.5
- Alternate: (empty field)

Accessing via Web Browser



The IP cameras are supported by Microsoft Windows Operating System.

! In Internet Explorer you can access the camera with Matrix ActiveX plugin. In other browsers you need to install Quicktime or VLC plugin.


- Run the Web Browser as Administrator.
- In the browser address bar, type the IP address of the camera e.g., 192.168.1.126 and press the Enter key to open the login interface.



- Enter the User Name and Password.
- By default, you can login with User Name as **admin, operator** or **viewer** with the password as **admin, operator** and **viewer** respectively.
- Click on Login.



- The browser will ask you to install ActiveX control.
- Click on Run Add-on to install the plugin.



- The ActiveX control will get installed on your PC.
- Now you can **Run** the plugin.



- Install the Camera software by clicking on **Install**.



- The Home page of the camera will open and the live view will be displayed.



- The camera configuration can be set from the Configuration tab.

Technical Specification

Specification	Standard
Power Supply	
Power Consumption	2MP: Max:5W 5MP: Max:6W
Connectors	
DC Connector	Yes (12V,2A)
M12 4-Pin Female Connector	Yes
Built-in-Mic	Yes
Audio IN	Yes
Audio Out	Yes
Alarm Out	Yes
Alarm In	Yes
Casting	
Material	Metal
Colour	Infinity White
Physical	
Dimensions	121mm x 119mm x 63mm (L x W x H)
Weight	600 gm (Approx.)

Technical Specification

Specification	Standard
Storage	
NAS	Yes
SD Card	Yes
Software	
IVA Events	Motion/No Motion Detection, View Tamper Detection, Trip Wire/No Trip Wire Detection, Zone/Object Intrusion
ONVIF Profile	S, G, T
Environmental	
Operating Temp.	-30 °C to +70 °C
Storage Temp.	-35 °C to +60 °C
Humidity	95% RH

Disposal of Product after End-Of-Life

WEEE Directive 2002/96/EC

The product referred is covered by the waste Electrical and Electronic Equipment (WEEE) directive and must be disposed of in a responsible manner.

At the end of product life cycle; batteries, soldered boards, metal components and plastic components must be disposed through recyclers.

If you are unable to dispose-off the products or unable to locate e-waste recyclers, you may return the products to Matrix Return Material Authorization (RMA) department.



SECURITY SOLUTIONS

MATRIX COMSEC PVT LTD

Head Office

394-GIDC, Makarpura, Vadodara, Gujarat, 390010, India

Ph: (+91)1800-258-7747

Email: Tech.Support@MatrixComSec.com

www.matrixvideosurveillance.com