

EON310

Executive Digital Key Phone



Quick Installation Guide



Thank you for choosing EON310! Please read this guide first for correct installation and retain it for future reference. The information in this guide was current at the time of publication. All specifications are subject to change without notice.

This Guide is meant to help you install and connect the phone. For detailed installation instructions, refer to the System Manual.

Copyright


All rights reserved. No part of this document may be copied or reproduced in any form or by any means without the prior written consent of Matrix Comsec Pvt. Ltd.

Warranty

Limited Warranty. Valid only if primary protection is provided, mains supply is within limit and protected, and environment conditions maintained within product specifications. Complete warranty statement is available on our website: www.MatrixTeleSol.com

2.

Know Your EON310



- | | |
|-----------------------|-----------------------|
| 1 Ringer LED | 6 Dial Pad |
| 2 LCD Screen | 7 Volume increase key |
| 3 Navigation keys | 8 Speaker key |
| 4 Fixed Function keys | 9 Volume decrease key |
| 5 DSS keys | 10 Handset |

Navigation Keys

✓	The Enter Key; To enter the Menu. To make a selection in the Menu or to complete an action.
^	The Up Key; To scroll upwards when navigating the Menu/sub-menu.
v	The Down Key; To scroll downwards when navigating the Menu/sub-menu.
>	The Forward Key; To move the cursor.
<	The Back Key; To move the cursor. To go back one level in the Menu.
x	The Cancel Key; To abort a function or process. To exit a Menu.

Volume Keys

While talking,
Press **[+]** to increase and press **[-]** to decrease Speech volume.

When the phone rings,
Press **[+]** to increase and press **[-]** to decrease Ringer volume.

3.

What Your Package Contains

- Phone, Handset and Spring Cord
- Line Cord
- A Foot Stand
- A Warranty Card Set
- Wall Mounting Template
- Quick Installation Guide (printed copy)


Installing EON310

Step 1 SELECT A LOCATION


You can mount the phone on a wall or on the desk.

Mount EON310 on a Wall

- Use the mounting template to drill holes of appropriate size and distance.
- Fix the screw grips in the holes you drilled.
- Fix two screws in the holes on the wall, ensuring that they are aligned with the Keyhole Slots 1 and 2 of EON310. The screws should protrude from the wall to fit into the Keyhole Slots.




- Now, mount the phone with the screws fitting into the Keyhole Slot.
- Reverse the handset wall mount tab to make sure the handset remains intact when you mount the phone. Push the handset wall mount tab upwards to remove it from the slot. Rotate it 180 degrees clockwise and push it downwards into the slot.




4.


Mount EON310 on the Desk



- You can attach the Foot Stand in the following ways - at an angle of 35 degrees and 50 degrees.




Stand attached at
35 degree angle




Stand attached at
50 degree angle

5.

Step 2 CONNECT






Connect the Handset

- Connect the handset of the EON310 to the phone body using the Spring Cord (supplied with the phone).
- Connect the long straightened end of the Spring Cord into the RJ9 connector on the left side panel of the phone, marked with the symbol .

Connect the Headset (not supplied by Matrix)

If you want to use a Headset,

- Plug any standard stereo headset with 3.5mm single connector into the headset jack on the left side panel of the phone, marked with the symbol .
- You may also plug in a headset with RJ9 connector into the headset port on the left side panel of the phone, marked with the symbol .




Connect the cable

- Plug one end of the Line Cord supplied with the phone into the RJ11 connector of EON310 labeled as 'LINE' and the other end into the wall jack / DKP port.

6.

Step 3 STARTUP AND OPERATE

- When the System is powered ON, the EON will reset. The EON communicates with the System. The handshaking lasts for 5-6 seconds. The EON model, version and revision number, along with the message 'Please wait...' appears on the LCD display.
- After successful handshaking and reset cycle, the extension number, day, date and time will appear on the LCD of the phone.



- To configure the name and extension number, refer to the *System Manual*. You can now access the features of the System from the EON310. For operating instructions, refer to the *EON48_310_SPARSH VP248_310_User Guide*.

The documentation can be found at

<http://www.matrixtelesol.com/technical-document.html>



MATRIX COMSEC

Head Office

394-GIDC, Makarpura, Vadodara - 390010, India

Ph: +91 265 2630555

E-mail: Support@MatrixComSec.com

www.MatrixTeleSol.com